



ASSEMBLY INSTRUCTION

CONFETTI CONSOLE TABLE




ROWICO

HOME




Ax1 	Ex8
Bx2 	Fx8
	Gx8
Cx2 	Hx4
	Ix4
Dx2 	Jx1

①



②



③

